



MG216 RF Module User Guide

I. Names of each parts



1. RF Module



2. RG202 Mini Receiver



3. RG202 Pro receiver



II. Firmware upgrade

1. RF module

1.1 Operation steps

- (1) Press and hold the **[SET]** key, connect TYPE-C to the USB port of the computer with a data cable (sold separately) to enter the forced upgrade mode. Indicator status: the red light is always on.
- (2) Short press **[SET]** key to select mode
Module upgrade: indicator status: blue light always on
- (3) Long press **[SET]** key to enter the upgrade state. Indicator status: blue light flashes

1.2 Computer terminal operation

First upgrade

(1) Install the driver

(2) Open the decompressed **【Driver】** folder:

For 64-bit operating system, please install **【dpinst_amd64.exe】**, double-click to run the installer, and the corresponding driver will be executed automatically. Install. For 32-bit operating systems, please install **【dpinst_x86.exe】**, double-click to run the installer, and the corresponding driver will be installed automatically. After the driver is installed! The module or receiver can be upgraded.

Non-first upgrade


(1) Open **【MG216 V1.0.1.exe】** (the version number will be different due to different release versions)

(2) When the drop-down bar shows **【STM Device in DFU Mode】**, you can enter the upgrade normally.

(3) Click **【Upgrade】** to start the upgrade.

(4) After the upgrade is completed, the indicator light status: red light flashes.

Note: If the upgrade indicator is stuck or the red light does not flash after the upgrade is completed, please turn off the power and follow the above steps to upgrade again.



1.3. Indicator status

Operation	Function	Mode	Indicator status
Short press	Switch function	RF Module	Blue light always on
		Receiver	Green light always on
Long press	Confirm	RF module upgrade	Blue light flashes
		Receiver upgrade	Green light flashes

2. Receiver (wireless upgrade)

Receiver and RF module operation

2.1 Receiver operation

(1) Press and hold the **【SET】** key, receiver power on again, the indicator status: the blue light flashes

2.2 RF module operation

(1) Press and hold the **【SET】** key, connect the TYPE-C to the USB port of the computer with a data cable (sold separately) to enter the mandatory upgrademodeType, indicator status: red light is always on.

(2) Short press **【SET】** key to select modeReceiver upgrade: indicator status: greenlight

(3) Long press **【SET】** key to enter the upgrade state. Indicator status: green light flashes

2.3 Computer terminal operation

First upgrade

(1) Install the driver

(2) Open the decompressed **【Driver】** hardware driver folder:

For 64-bit operating system, please install **【dpinst_amd64.exe】**, double-click to run the installer, and the corresponding driver will be installed automatically.

For 32-bit operating systems, please install **【dpinst_x86.exe】**, double-click to run the installer, and the corresponding driver will be installed automatically. After the driver is installed! The RF module or receiver can be upgraded

Non-first upgrade

(1) Open **【Receiver V1.0.1.exe】** (the version number will be different due to different release versions)




(2) When the drop-down bar shows **【STM Device in DFU Mode】**, you can enter the upgrade normally.

(3) Click **【Upgrade】** to start the upgrade.

(4) After the upgrade is completed, the indicator light status: red light flashes.

Note: If the upgrade indicator is stuck or the red light does not flash after the upgrade is completed, please turn off the power and follow the above steps to upgrade again.

Note: When upgrading, only 1 pair of RF module and receiver are being upgraded, otherwise the upgrade may fail.



III. Indicator status

1.RF module

Mode	Color	Status	Function
CRSF	Green	Always on	Connected receiver
S.BUS	Blue		Connected receiver
PPM	Purple		Connected receiver
Warn	Yellow		Receiver not nonnected
	Red	Flashes	Voltage<6.8v
		Always on	No transmitter data received
Link	Yellow	Flashes	Linking

2.Receiver

Mode	Color	Status	Function
Link mode	Yellow	Flashes	Linking
	Green	Always on	Finish
Transmission mode	Red	Always on	No transmitter data received
Warn		Flashes	Voltage<3.7v

IV. Link

1. RF module

(1) Method 1 **【SET key linking】**

When the RF module does not receive data from the receiver (indicator status: yellow, blue, or purple light is always on), long press the **【SET】** button to enter the linking status, and the indicator status: the yellow light flashes.

(2) Method 2 **【Menu linking】**


Open TX system

【MODEL SETUP】 - 【External RF】 - 【Mode】 When the protocol is set to CRSF, the function setting will be displayed. Long press the transmitter **【SYS】** key to enter the **【TOOLS】 - 【Crossfire configure】 - 【WFLY TX】** function interface. In the WFLY TX interface, press the **【Bind】** key to bind.

WFLY ET16/S

Function path: **【Linkage setting】 -【Bind】**

- ① The built-in module is set to **【Disabled】**
- ② Set the external module to **【W.CRSF】**
- ③ Click **【Start】** to check the code.



2. Receiver

(1) Linking mode within 0.13 seconds after power-on

Note: The RF module status needs to be in the linking mode.

(2) Long press the **【SET】** key to enter the link state, the indicator light state: the yellow light flashes.

Note: After the code is successfully link, if you need to enter the link again, the receiver needs to be powered on again. Long press **【SET】** key to exit the linking mode.

V. How to use the RF module

1. The type of protocol supported by the module:

S.BUS, CRSF, PPM protocol, for example: Open TX system, long press the transmitter **【MDL】** key, **【MODEL SETUP】 - 【External RF】 - 【Mode】** setting items, respectively set to CRSF, S.BUS, PPM, The module can be identified and connected normally.

Tips: CRSF protocol: support interface function settings,

PPM protocol: **【MODEL SETUP】 - 【External RF】 - 【PPM frame】** on the OPEN TX system should be set to 300us. PPM protocol supports up to 16 channels

MODEL SETUP	
Use global funcs	
Internal RF	
Mode	OFF
External RF	
Mode	CRSF
Channel Range	CH1-CH16
Receiver	00
Trainer	
Mode	Master/Jack

MODEL SETUP	
Use global funcs	
Internal RF	
Mode	OFF
External RF	
Mode	SBUS
Channel Range	CH1-CH16
Refresh rate	7.0ms normal
Warning:output level is VBAT:	7.44V
Trainer	

MODEL SETUP	
Use global funcs	
Internal RF	
Mode	OFF
External RF	
Mode	PPM
Channel Range	CH1-CH8
PPM frame	22.5ms 300us
Trainer	
Mode	Master/Jack

2.WFLY TX interface

[MODEL SETUP] - [External RF] - [Mode] When the protocol is CRSF, the function setting is displayed. Long press the transmitter **[SYS]** key to enter **[TOOLS] - [Crossfire configure] - [WFLY TX]** function interface.

TOOLS
01 Crossfire configure
02 FrSky GaSuite
03 FrSky SBEC
04 FrSky SxR
05 Graupner HoTT
06 Spectrum(INT)



CROSSFIRE SETUP
WFLY TX
WFLY RX



WFLY TX	
Set Failsafe	
Bind	
Bind.Parameter	
Re-Flag	Enable
Re-Num	1
TX .Power	5mW
Transfer_Mode	P2P
L_Freq	1
H_Freq	100
Firmware:	V1.0.1

(1) Set Failsafe (out of control protection setting)

Set the fail-safe protection function, and send the current channel data to the receiver
 Note: Only when the **[TOOLS] - [Crossfire configure] - [WFLY RX]** mode is **[F/S]**, data will be sent to the receiver

(2) Bind

Binding: All parameters need to be set, and then the code pairing operation is performed before the interface data will be sent to the receiver.

Re-Flag: When returning the flag **[Disable]**, the receiver does not return information to the module

Re-Num: The number of return times (1/2/3/4/5), for example: when set to 2, the receiver will return 1 packet of high-frequency header data only after receiving two packets of data.

Transfer_Mode: transfer mode setting

[P2P]: The RF module can only be connected to one receiver;

[Radio]: The RF module can be connected to multiple receivers at the same time

L_Freq: minimum frequency limit

Range: 1~25 (for example: when set to 1, the frequency is 2.401GHz)

Step value: 1Mhz

H_Freq: Maximum frequency limit (76~100),

Range: 76~100


Step value: 1Mhz

(3) TX.Power: The transmitting power setting of the RF module, which can be set to 5mw/10mw/25mw/50mw/100mw.

(4) Firmware: RF module firmware version

3. WFLY RX interface

[MODEL SETUP] - [External RF] - [Mode] When the protocol is CRSF, the function setting is displayed. Long press the transmitter **[SYS]** key to enter **[TOOLS]** - **[Crossfire configure]** - **[WFLY RX]** function interface.



(1) Set TX.Power: Receiver power setting Receiver transmit power setting, which can be set to 5mw/10mw/25mw/50mw/100mw.

(2) Set RX.Port: receiver port setting

Before setting the receiver port configuration, first select the parameters of the receiver port, and then set it

RX-Port.W_R: Read: Port information read from the receiver.

Write: Set the receiver port.

RX-Port1.mode: can be set to PWM or PPM.

RX-Port1.ch: can be set to CH1 to CH16

Port 1-7: Can be set to PWM or PPM, and support channels 1 to 16 to be mapped to this port.

Port 8 and 9: can be set to PWM, PPM, W.BUS or CRSF mode

PWM: channels 1-16 can be set to map to this port;

PPM: Correspondence containment channels 1 to 9 are mapped to this port

(Set to channel 1, the PPM output is CH1 to CH8 channel data; set to channel 9, the PPM output CH9 to CH16 Channel data);

WBUS: This port outputs W.BUS data;

CRSF: This port outputs CRSF data;

Example: RX-Port8.mode=PWM, RX-Port8.ch=CH2, then the receiver port 8 outputs the PWM data of channel 2.

(3) Steps to set the receiver port

- ① **【RX-Port.W_R】 Set to 【Write】**
- ② **Set the 【RX-PortX.mode】 and 【RX-PortX.ch】 functions separately;**
- ③ **Set 【Set RX.Port】 , select 【OK】**

WFLY RX	
General	
Set TX.Power	100mW
Set Servo	
Set-Servo.Parameter	
Servo.w_R	Read
Servo.Frq	50Hz
Servo.Angle	Angle_180
Set RX.Port	
Set RX.Port.Parameter	
RX-Port.W_R	Read
RX-Port1.mode	PWM

WFLY RX	
RX-Port4.ch	CH4
RX-Port5.mode	PWW
RX-Port5.ch	CH5
RX-Port6.mode	PWW
RX-Port6.ch	CH6
RX-Port7.mode	PWW
RX-Port7.ch	CH7
RX-Port8.mode	W_BUS
RX-Port8.ch	----
RX-Port9.mode	W_CRSF
RX-Port9.ch	----

Set RSSI.ch	OFF
Set SNR.ch	OFF
Set LQ.ch	OFF

(4) SNR/RSSI/LQ mapping settings

RSSI/SNR/LQ: Can be mapped to output channels 1 to 16.

RSSI/SNR/LQ: OFF/CH1–CH16

Example: LQ is mapped to CH12, 12 data of output protocol CRSF/W.BUS is LQ setting steps:

Set the channel mapped by RSSI/SNR/LQ and select **【OK】** .

W.BUS_cycle(ms)H_speed	
CRSF_cycle	H_speed
CRSF_W.BUS_Out	Standard
Failsafe_Mode	F/S

(5) W.BUS_Cycle(ms): W.BUS output cycle setting

Can be set to H_Speed/7/8/9/10/11/12/13/14

H_Speed: High speed mode,

When set to 7-14: W.BUS data is output once every 7-14ms

(6) CRSF_Cycle: Set CRSF output cycle

Can be set to H_Speed, Standard

H_Speed: High speed mode

Standard: Standard mode

Setting steps: Set the period of CRSF output, select **【OK】** .

(7) CRSF_W.BUS_Out: CRSF, W.BUS output positive and negative settings

Can be set to Standard, Inversion

Standard: Standard;

Inversion: Inversion. (Some flight controllers only recognize the inversion of the CRSF or W.BUS protocol, and can be used normally when set to inversion) Setting

steps: set CRSF, WBUS output protocol standard or reverse phase, select **【OK】** .

(8) FailSafe_Mode: Set the fail-safe protection mode

Can be set to Keep, F/S, Close mode


F/S, the receiver will use the channel data received at this time as the out-of-control protection data,

Keep, Close, only change the receiver out-of-control protection mode, and will not change the out-of-control protection data.

Note: When set to Keep or Close, when the fail-safe protection is set in the **【TOOLS】** - **【Crossfire configure】** - **【WFLY TX】** interface, only the receiver fail-safe mode will be changed, and the fail-safe data will not be changed.

4. Telemetry interface

When the module is connected to the receiver normally, long press the **【MDL】** key to jump to the **【TELEMETRY】** telemetry interface.



TELEMETRY				
Disable telemetry alarms				
Sensors		Value		ID
1:	1RSS	*	-62dB	0
2:	2RSS	*	-62dB	1
3:	RQly	*	100%	2
4:	RSNR	*	12dB	3
5:	ANT		---	4
6:	RFMD	*	2	5
7:	TPWR		---	6

5. Receiver number

Long press **【MDL】** key, when **【MODEL SETUP】** - **【External RF】** - **【Mode】** is **【CRSF】** mode, **【Receiver】** The serial number data is sent to the receiver during code matching. And the RF module and receiver will recognize this number when they are connected.

MODEL SETUP	
Use global func	
Internal RF	
Mode	OFF
External RF	
Mode	CRSF
Channel Range	CH1-CH16
Receiver	00
Trainer	
Mode	Master/Jack

Example: When the **【Receiver】** number is set to **【0】** , the RF module and the receiver are successfully connected after the code is successfully paired. When the **【Receiver】** number is set to **【1】** , the RF module and the receiver are disconnected, **【Receiver】** When the number is reset to 0, the RF module and receiver resume normal connection.

VI. Technical parameters

Product model: MG216

Support: ET16 ET16S Open TX (Includes JR slo)

Frequency band: 2.4GHz

working frequency: 2.400-2.483 GHz

Modulated emission: LoRa

Adjustable position: Power adustable

Transmit power: 20dBm

Flying range: >3km (No interference,open area)

High refresh rate: 200/135Hz

Delay: 5ms (CRSF)

Transmission channel: 16

Set interface: Support LUA script (OpenTX)

Antenna type: External single antenna

Antenna interface: Internal thread inner hole

Antenna gain: 3dbi

Power supply range: 3.5~13V

Product dimensions: 65mm*53mm22mm

Power consumption: 0.36W

Weight: 45.0g (including antenna)

Installation slot size: 60.mm*45mm19.5mm

Online upgrade: Suppor

Signal input: CRSF、 S.BUS、 PPM

Wireless protocol: Third Generation

Shenzhen WFLY Technology Development Co., Ltd
 C3 Buliding,Xiangli Industry Park,Heping Haoye Road,Fuyong
 Town,Baoan District,Shenzhen,Guangdong Province,China
www.wflysz.com